





零件清單




Ax1




Bx1




Cx1




Dx2



Ex2



Fx4



screw



M8*65

Gx4

screw



M6*6

Hx17

screw



M6*10

Ix5

hex wrench



4MM

Jx1

hex wrench



5MM

Kx1

screw



M6*15

Lx1

screw



Mx1


screw



M8*10


Nx7

Step 1




If the stand needs to fit under a gap less than 5cm in height you can use the original wheels in order to minimize the height and not the wheels marked "F".

Step 2



Step 3


Note: Do not place your body above the lifting rod to prevent the injury from accidental operation.




Note: When lifting and lowering please depress the pedal with one foot and use your hands to lift or lower the stand. When you have reached the desired height the pedal can be released.

單片面板・橫向安裝


Step 4




Step 5



Step 6




Step 7




兩片面板拼接・橫向安裝


Step 4




Step 5



Step 6




Step 7




加長面板・橫向安裝


Step 4




Step 5




Step 6




Step 7






1. loose the B1
2. screw the B2 out



3. rotate the panels to the vertical position
4. tighten the screw B1 and B2



支架尺寸



Note: Maximum load capacity
25KG/55LBS